
Ejector, Series EBS

R412007447

AVENTICS Series EBS Ejectors

The AVENTICS Series EBS ejectors are the convincing and talented multi-taskers within the AVENTICS ejector Series. Parallel to the main advantages of this ejector Series, these ejectors offer additional benefits due to their enormous versatility.





Technical data

Industry Industrial
Activation Pneumatically
Note push-in fitting
Type Ejector

Version pneumatic control, inline form

Nozzle Ø 0.5 mm

Min. working pressure 3 bar

Max. working pressure 6 bar

Min. ambient temperature 0 °C

Max. ambient temperature 60 °C

Min. medium temperature 0 °C

Max. medium temperature 60 °C

Medium Compressed air

Min. oil content of compressed air 0 mg/m^3 Max. oil content of compressed air 1 mg/m^3 Max. particle size $5 \text{ }\mu\text{m}$ Compressed air connection \emptyset 4 Vacuum connection+ \emptyset 4 Max. suction capacity 8 l/min



Ejector, Series EBS

R412007447

Air consumption at p.opt.	13 l/min
Max. vacuum level at p.opt	83 %
Sound pressure level intake effect	52 dB
Sound pressure level intake effect	60 dB
Weight	0.005 kg

Housing material Polyamide fiber-glass reinforced Seal material Acrylonitrile butadiene rubber

Nozzle material Aluminum


Material release ring Polyamide

Part No. R412007447


Technical information

Note: All data refers to an ambient pressure of [[1,013] bar] and an ambient temperature of [[20]°C]. The pressure dew point must be at least 15 °C less than ambient and medium temperature and may not exceed 3 °C.

Dimensions




Air consumption qv depending on working pressure p1



^{1) =} Ø nozzle 0.5 mm 2) = Ø nozzle 0.7 mm

Evacuation time tE depending on vacuum p2 for 1 I volume (with optimal operating pressure p1opt)




1) = Ø nozzle 0.5 mm 2) = Ø nozzle 0.7 mm



³⁾ optimum working pressure


R412007447

Suction capacity qs depending on working pressure p1



- 1) = \emptyset nozzle 0.5 mm 2) = \emptyset nozzle 0.7 mm
- 3) optimum working pressure

Vacuum p2 depending on working pressure p1



- 1) = \emptyset nozzle 0.5 mm 2) = \emptyset nozzle 0.7 mm 3) optimum working pressure