
Pneumatic counters





Technical data

Industry Industrial Mounting orientation Any

Medium Compressed air

Display 6 digits

Logic function Pneumatic/mechanic counter, adding

Return Manually via a button

Pneumatically

M5

Compressed air connection input

Min. working pressure2 barMax. working pressure8 barPulse duration counting> 18 msPulse duration return> 180 msPause duration counting> 10 ms

0821304004

Pause duration return > 50 ms
Weight 0.073 kg
Part No. 0821304004

Technical information

The pressure dew point must be at least 15 °C less than ambient and medium temperature and may not exceed 3 °C.


The min. control pressure must be adhered to, since otherwise faulty switching and valve failure may result!

The pressure dew point must be at least 15 °C less than ambient and medium temperature and may not exceed 3 °C.

The oil content of compressed air must remain constant during the life cycle.

Use only the approved oils from AVENTICS. Further information can be found in the "Technical information" document (available in https://www.emerson.com/en-us/support).


Fig. 3



Z = counting signal Y = return signal

Included in the delivery contents: 2 oval head countersunk screws DIN 966 St M4 x 16 2 spring rings A4 DIN 127 2 hexagonal nuts M4 DIN 934


Fig. 2





Z = counting signal Y = return signal


D = reset key
Included in the delivery contents: 2 oval head countersunk screws DIN 966 St M4 x 16 2 spring rings A4 DIN 127 2 hexagonal nuts M4 DIN 934

Fig. 1










Z = counting signal
Y = return signal
C = countersink DIN 74-Af4
D = reset key
Included in the delivery contents: 2 oval head countersunk screws DIN 966 St M4 x 16 2 spring rings A4 DIN 127 2 hexagonal nuts M4 DIN 934

Counting frequency



- 1) Counting impulse
 2) Response pressure -[[0.8] bar
 3) Release pressure -[[0.15] bar]
 ti = min. pulse duration tp = min. pause duration tz = time for counting pulse
 = ti + tp + 2t* t* = dependent on pressure and pipe length (values must be determined)