#### R412006251

### **Series AS2**

The AVENTICS Series AS2 is a modular, versatile maintenance unit for universal application. This Series offers compact dimensions, is highly efficient, lightweight and easy-to-use. The AVENTICS Series AS guarantees reliability, safety, and efficiency with a simplified assembly and maintenance efforts.





### Technical data

Industry Industrial
Parts Distributor
Port G 3/8

Type Can be assembled into blocks

Version Distributor 3x

Mounting orientation Any
Min. working pressure 0 bar
Max. working pressure 16 bar
Min. ambient temperature -10 °C
Max. ambient temperature 50 °C

Medium Compressed air

Neutral gases

Nominal flow Qn 3600 I/min
Nominal flow Qn 1 to 2 3600 I/min
Nominal flow Qn 1 to 3 2000 I/min
Nominal flow Qn 1 to 4 900 I/min
Nominal flow Qn 1 to 5 2000 I/min
Weight 0.25 kg

Housing material Polyamide

Material front plate Acrylonitrile butadiene styrene

R412006251

Seal material Acrylonitrile butadiene rubber

Material threaded bushing Die cast zinc R412006251

## **Technical information**


The pressure dew point must be at least 15 °C less than ambient and medium temperature and may not exceed 3 °C.


Suitable for direct mounting of a PE2 and PM1 series pressure sensor (flange version).


A change in the flow direction (from air supply on the left to air supply on the right) occurs by rotating installation by 180° about the vertical axis. Please see the operating instructions for further details.


Nominal flow Qn with secondary pressure p2 = 6 bar at  $\Delta p$  = 1 bar


# Dimensions in mm












A1 = input
A2 = output
A3 = output
A4 = output
A5 = output
A5 = output
1) Mounting thread for pressure sensor

# Accessories overview



<sup>1 =</sup> contamination display 3 = Double nipple 4 = Key for E11 locking 5 = mortise lock 6 = Transition plate DO30 7 = Adapter, Series CON-VP 8 = Mounting aid DO16, form C 9 = Mounting aid DO16, M12 10 = Adapter for external pilot air 11 = Adapter pneumatic operation 12 = Sealing ring