AVENTICS Series PE5 Pressure sensors

The AVENTICS Series PE5 is an electronic pressure sensor, which combines electronic precision and versatile functions with ideal user friendliness.





Technical information

Industry Industrial

Output signal 2 x PNP, NPN, Push-pull

Type electronic

Operating pressure min -1 bar Operating pressure max 1 bar Protection against overpressure 5 bar

17-30 V DC Operational voltage

Switching logic NO/NC (adjustable) Max. shock resistance 30 g

Vibration resistance 5 g (10 - 150 Hz)

Precision (% of full scale value) ± 0,2 %

Hysteresis adjustable Measurement Relative pressure

LCD display, 4 digits Display

Color setting: green or red

Units displayed bar psi kPa MPa inHg

G 1/4 Compressed air connection

Compressed air connection type Internal thread

Min. medium temperature 0°C 60 °C Max. medium temperature

Medium Compressed air (max. 40 µm) Certificates CE declaration of conformity

> cULus **RoHS**

Conforms with REACH

Free of substances that impair surface wetting in

the coating process

Electrical connection type Plug Electrical connection size M12x1 Electrical connection number of poles 4-pin 0°C Min. ambient temperature 60 °C Max. ambient temperature Max. oil content of compressed air 40 mg/m³ Switching time < 5 ms

adjustable 0 ... 100% Resetting point adjustable 0 ... 100% Switching point

<40 mA Quiescent current consumption Delayed hysteresis adjustable

<± 0.5% of the final value Analog output linearity

Maximum load (analog current output) 600Ω Protection class **IP65**

IP67 with connections assembled

Max. 600 ohms (current output) Short circuit resistance Min. 3K ohms (voltage output)

Mounting types Directly on hat rail and wall mounting

For panel installation using mounting kit

via double nipple

0.04 kg Weight

Material

Housing material Polycarbonate

Seal material Acrylonitrile butadiene rubber

Material electrical connection **Aluminum** Part No. R412010763

Technical information

Alternative pressure connection (G1/4) on the rear side (closed with plug)


Display color selectable, red or green

The pressure dew point must be at least 15 °C less than ambient and medium temperature and may not exceed 3 °C.

The oil content of compressed air must remain constant during the life cycle.

Use only the approved oils from AVENTICS. Further information can be found in the "Technical information" document (available in https://www.emerson.com/en-us/support).

push-in fitting




¹⁾ M12x1 electrical connection

²⁾ Mounting for hat rail and wall mounting

³⁾ Alternative pressure connection (G1/4) closed with plug

⁴⁾ Pressure connection, tubing Ø 4 mm

Internal thread




- 1) M12x1 electrical connection
- Mounting for hat rail and wall mounting
 Alternative pressure connection (G1/4) closed with plug
 Pressure connection G1/4

Electr. connection for leak test




Display and operation area




- 1) LCD display
- 2) Control panel with 3 buttons

Leakage characteristic




- Internally stored parameter
 Adjustable parameter
 Output value


Operating mode Push-pull




Operating mode NPN




Operating mode PNP



Hysteresis function: switching and resetting behavior dependent on pressure p and time t In case of underpressure



Hysteresis function: switching and resetting behavior dependent on pressure p and time t In case of overpressure




H: Hysteresis




SP = switching point RP = resetting point

Out (NC): switch output, break contact Out (NO): switch output, make

Delayed hysteresis function: switching and resetting behavior depending on pressure p and time t



Window function: switching and resetting behavior depending on pressure p and time t



H: Hysteresis

SP = switching point RP = resetting point

Out (NC): switch output, break contact Out (NO): switch output, make contact

dS: switching delay dR = reset delay


1) period of pressure over the switching point < dS: pressure sensor does not switch 2) Period of pressure over the switching point > dS: pressure sensor switches 3) Period of pressure under the resetting point > dR: pressure sensor switches

FH: pressure band, upper value

FL: pressure band, lower value


Out (NC): switch output, break contact Out (NO): switch output, make contact

Block diagram 1x PNP and 1x analog




RL = storable postion

Block diagram 1x NPN and 1x analog




RL = storable postion

Pin assignments M12x1 4-pin



Pin assignments M12x1 5-pin



Pin assignments

Pin	Allocation
1	Supply Voltage
2	Switch output PNP/NPN/push-pull, switchable
3	0 V
4	Switch output PNP/NPN/push-pull/leakage mode, digital switch input PNP
5	Analog output (0 to 10 V DC, 4 to 20 mA)